


BS400 Solar Hybrid Tracker




Tracker must be turned on.
Press this button for a second.

Tracker can be connected to 8-24v DC power; a connecting cable (not included) is attached to this port.



These lights illuminate to indicate the tracker is on. Make sure to place the tracker in sunlight periodically to recharge the batteries.



Affix tracker to equipment. Use 4 bolts

and/or the adhesive strip.

Note - a magnetized version of this tracker is also available.